
Please first read this manual carefully.

front side - Installing a G-Motion motor unit on a Qurails 6200 curtain rail system.


back side - Setting end positions.

Overview components




cover: remove to access connector-area and basic controlling buttons

2 Identification motor type




"1" X NO auto calibration, see other Quickmanual GM1


Connector area




4 Adjust blocking positions (If needed)





(Split stack:)




5 Mounting motor unit










6 Powering

Firs

First use: if NOT mounted on a 6200 rail system, the motor unit will run in one direction only.















* calibration only with 4 or 5 core wiring AND 'L' connected, or with special calibration cable Button instruction:



First use: if NOT mounted on a 6200 rail system while setting end positions, the motor unit will run in one direction only.

